

1 YEAR
WARRANTY



User's Guide



Shop online at

omega.com®

OMEGA®

omega.com

e-mail: info@omega.com

For latest product manuals:

omegamanual.info

ISO 9001
CERTIFIED
CORPORATE QUALITY
STAMFORD, CT

ISO 9001
CERTIFIED
CORPORATE QUALITY
MANCHESTER, UK

MADE IN TAIWAN

HH147 Handheld Thermometer K/J/T/E/R/S/N Types

omega.com®

an OMEGA®

OMEGAnet® On-Line Service
omega.comInternet e-mail
info@omega.com**Servicing North America:****U.S.A.:**ISO 9001 Certified

OMEGA Engineering, Inc.

One Omega Drive,

P.O. Box 4047

Stamford, CT 06907-0047 USA

Toll-Free: 1-800-826-6342

TEL: (203) 359-1660

FAX: (203) 359-7700

e-mail: info@omega.com

Canada:

976 Bergar

Laval (Quebec), Canada H7L 5A1

Toll-Free: 1-800-826-6342

TEL: (514) 856-6928

FAX: (514) 856-6886

e-mail: info@omega.ca

For immediate technical or application assistance:**U.S.A. and****Canada:**

Sales Service: 1-800-826-6342/1-800-TC-OMEGA®

Customer Service: 1-800-622-2378 1-800-622-BEST®

Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

Mexico:

En Español: 001 (203) 359-7803 FAX: (001) 203-359-7807

info@omega.com.mx

e-mail: espanol@omega.com

Servicing Europe:**Benelux:**

Managed by the United Kingdom Office

Toll-Free: 0800 099 3344

TEL: +31 20 347 21 21

FAX: +31 20 643 46 43

e-mail: sales@omega.nl

Czech Republic:

Frystatska 184

733 01 Karviná

Czech Republic

Toll-Free: 0800-1-66342

TEL: +420-59-6311899

FAX: +420-59-6311114

e-mail: info@omegashop.cz

France:

Managed by the United Kingdom Office

Toll-Free: 0800 466 342

TEL: +33 (0) 161 37 29 00

FAX: +33 (0) 130 57 54 27

e-mail: sales@omega.fr

Germany/**Austria:**

Daimlerstrasse 26

D-75392 Deckenpfronn

Germany

Toll-Free: 0 800 6397678

TEL: +49 (0) 7059 9398-0

FAX: +49 (0) 7056 9398-29

e-mail: info@omega.de

United**Kingdom:**ISO 9001 Certified

OMEGA Engineering Ltd.

One Omega Drive,

River Bend Technology Centre, Northbank

Irlam, Manchester M44 5BD England

Toll-Free: 0800-488-488

TEL: +44 (0)161 777-6611

FAX: +44 (0)161 777-6622

e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications.


Table of Contents

Introduction	1
Features	2
General Specifications	3
Electrical Specifications	4
Names of Parts	5
Operation	6
RS-232 Operation	16
RS-232 Installation Proceedure	24
RS-232 Operation of Software	26
Battery Replacement	34

■ Introduction

Thank you for purchasing model HH147, RS232 Data Logger Thermometer. Please take a few minutes to browse through this user manual before you begin to operate the unit to ensure that you are fully familiarized on how to best operate the meter.

The model HH147 features a microprocessor-rated digital temperature gauge.



■ Features

1. Displays maximum value for four temperatures.
2. Resolution: 0.1°C/0.1°F, 1°C/1°F.
3. Swift response.
4. Alert temperature range, setting.
5. Auto power off function.
6. Low battery indicator function.
7. Perpetual calendar function.
8. "Count" function.
9. T1-T4 exchange to main display function.
10. T1-T2, T3-T4 function.
11. Additional features: HOLD, °C/°F, REL, CHAN, MAX/MIN/AVG, 1°, TYPE, TIME (CLOCK setting), LIMIT (HiLo setting).
12. CE certified, according to ITS-90.

■ General Specifications

1. Display Mode: Four-digit liquid crystal display.
2. Polarity indicator: No indicator is shown when readouts are in the positive value while the symbol “-” is prompted when readouts fall into the negative value.
3. Overload indicator: “OL” or “-OL” is displayed.
4. Low battery indicator: The symbol “**B**” is prompted on the LCD when the battery runs low.
5. Power source: Four AAA batteries.
6. Auto power off: The unit powers down after 20 minutes of operation. Press the “Shift” key for 3 seconds, the auto power off will be disabled.
7. Sample rate: 1 time/sec.
8. Battery life: Approx. 550 hours.
9. Operating Temperature and Humidity:
0°~50°C (32°~122°F), 0~80%RH
10. Storage Temperature and Humidity:
-20°~60°C (-4~140°F), 0~80%RH.
11. Dimension: 164x76x32mm (LxWxH).
12. Weight: approx. 415g (includes batteries).
13. Accessories:
 - (A) AAA Battery (4pcs).
 - (B) Housing (1pc).
 - (C) K-type thermocouple wire (4pcs).
 - (D) Users manual (1pc).
 - (E) RS-232 cable (1pc).
 - (F) RS-232 software CD (1pc).

■ Electrical Specifications

1. Temp. unit: Celsius temp. (°C). Fahrenheit temp. (°F), Absolute temp. (K).
2. Measurement Range: (At 23±5°C, <80%RH)
K-type: -100~1300°C (-148~2372°F)
J-type: -100~1000°C (-148~1832°F)
T-type: -100~400°C (-148~752°F)
E-type: -50~800°C (-58~1472°F)
R&S-type: 0~1700°C (32~3092°F)
NK-type: -100~1300°C (-149~2372°F)
3. Accuracy: The basic accuracy does not include the error of the thermocouple.
K/J/T/E/-type:
±(0.1% reading +0.7°C) -100°~-1300°C
±(0.1% reading +1.4°F) -148°~2372°F
R/S-type:
±(0.1% reading +2°C) 0°~1700°C
±(0.1% reading +4°F) 32°~3092°F
N-type:
±(0.1% reading +1.5°C) 100°~1300°C
±(0.1% reading +3°F) 148°~2372°F
4. Resolution:

	1°C	0.1°C
K	-100°~1300°C	-100°~200°C
J	-100°~1000°C	-100°~150°C
T	-100°~400°C	-100°~150°C
E	-50°~800°C	-50°~100°C
R	0°~1700°C	
S	0°~1700°C	
N	-100°~1300°C	-100°~150°C

Names Of Parts



1.LCD display

2.Function control key

3.Thermocouple input jack

4.Battery cover

5.RS-232 input jack

6.Shift button

7.Power button

■ Operation

1. ① : Power ON/OFF Key.

Press the power button to turn the power ON or OFF.


2. °C/°F/K: The Temp. Unit Selection Key.

Press the key to sequentially alternate the three temp. units of °C, °F, and K.

3. HOLD: The Readout Hold Function Key.

Press the “HOLD” key, a “HOLD” icon will display on the LCD and the readout will be held in; press the “HOLD” key once more to cancel the “HOLD” function.

4. MAX/MIN/Avg: The Maximum/Minimum/Average Readout Function Key




■ Operation

5. REL: The Minus Relative Readout Function Key.

Press the “REL” key, a “REL” icon will display on the LCD and the original temp. will go to 0 and save the original temp. to make a standard value.

Whenever the input temp. shifts, the LCD will show the minus value of the original temp. value and input temp. value.



6.1°: 1° or 0.1° Unit Selection Function Key


Press the “1” key, the whole resolution will become 1°C/1°F, and eliminate the dot. Press the key again and the display will be restored to the common state (the resolution will become 0.1°C/0.1°F).

Note: The resolution of the thermocouple types is shown on page 4.

■ Operation


7.CHEN:every input temp. value changed to main display function key.

A.four channel:




■ Operation

- 8. TYPE:** Select a thermocouple type function key. HH147 includes seven different thermocouple types. The method of operation:




- A. Use , key to choose "type".
B. The word will flicker for the chosen "type".
C. To confirm it, press "SHIFT" key.

The type became "J" type.




■ Operation

- 8. COUNT:** The Count Time Setting Function Key.
The max count time is 99 hours and 59 minutes.




- 10. TIME:** To set the present time function key.




■ Operation

11.T1-T2:With T1-T2 function.




12.T3-T4: for four channel modes.




■ Operation

14.Hi/Lo: The alarm Hi/Lo temp.value setting.




■ Operation

15. CLOCK: To Enforce Date Setting Function Key.



■ Operation

16. Perpetual Calendar:




16. Backlight:


- A. Press the backlight button to turn the backlight ON or OFF.
- B. If you do not disable the backlight feature, the backlight will stay on for 1 minute.

■ Operation

1. RS-232: When you turn on the “RS-232” function the auto power off and the power off will be cancelled.




2. REC: When you turn on the “REC” function the reading value of the meter will transmit the settlement of interval in time, and will write down in the memory in real time. The maximum number of records is 10000 records at most. When turning on “REC” function, the auto power off and the power off will be cancelled. When the memory is filled, the display will show “ou”.




■ Operation

3. CALL: The HH147 can display the data of every channel, and can also inquire about the surplus space of the memory. When the "CALL" function is on, the auto power off will be cancelled.



■ Operation


4. **SHIFT** + **CALL** : remove the record of the memory.



5. **SHIFT** + **RS232** : When the RS-232 function is on the biggest settlement time is 59 minutes and 59 seconds. Minimum set time is one second.

■ Operation


5. (SHIFT) + [RS232] :



The flashing number represents adjustable number.

■ Operation

4. **SHIFT** + **REC** : When the record interval function is on, the biggest settlement time is 59 minutes 59 seconds. Minimum set time is 1 second.



The flashing number represents adjustable number.


■ RS-232 Data Form

Model-0 Data Form:


1. Sensor Form:

(1)

SEN 1




SEN 0



Sensor	K	J	T	E	R	S	N
Date	0	1	2	3	4	5	6

(2)

SEN 2



Bit 0~3:sensor type that can be used

0:K

1:KJ

2:KJT

3:KJTE

4:KJTER

5:KJTERS

6:KJTERSN

Bit 4~5:Channel

0:T1

1:T1,T2

2:T1,T2,T3

3:T1,T2,T3,T4

Bit 6:Model(0:T1~T4 Type adjustable
1:only T1 Type adjustable)

Bit 7:Unuse

■ RS-232 Data Form

Model-0 Data Form:

Transmit the time interval: Max. 59 minutes 59 seconds

TI1

7	4	3	0

Min (decimal)

TI0

7	4	3	0

Sec.(decimal)

2. Temperature value form

?_DECF3

7	4	3	0

?_DECF2

7	4	3	0

Integer(decimal)

?_DECF1

7	4	3	0

Bit 4: positive,negative(positive:0,negative:1)

Bit 5: Overflow

?_DECF1

7	4	3	0

?_DECF0

7	4	3	0

Fraction(decimal)

3. Transmit the form

L.C.	C.C.	S.C.	Date	E.C.
------	------	------	------	------

L.C.:0AA_H
E.C.:0AB_H

L.C.	C.C.	S.C.	Flag	E.C.
------	------	------	------	------

C.C.~

0BX_H:Model-0

0B1_H:Sensor, T.I, Temperature (Terminal→PC)

0B2_H:Sensor& T.I. (Terminal→PC)

0B3_H:Sensor& T.I. (PC→Terminal)

0B4_H:Data=10H, on-line confirm (PC→Terminal)

0B9_H:Answer"0B1_H"(PC→Terminal)

0BA_H:Answer"0B2_H"(PC→Terminal)

0BB_H:Answer"0B3_H"(Terminal→PC)

■ RS-232 Data Form

Model-0 Data Form:

S.C.~

Order code(00_H ~7F_H).The same data conveyed repeatedly,
the code does not change. On the
contrary, different data, this code
will add one in order.

Flag:

"30_H"= fail,"31_H"= success

Data:


C.C.=0BX_H

SEN 0~2, TI0~1, Tn0*


Tn0* : T1_DECF1~3, T1_DECF0, T2_DECF1~3, T2_DECF0,
_DECF1~3, T3_DECF0, T4_T3DECF1~3, T4_DECF0.

■ RS-232 Software Installation Procedure

1. Place CD-R into the CD-ROM driver.
2. Installation may be automatic or manual in accordance with your personal software. The manual installation is: A. Pushing my computer, the mouse clicked two times. B. Pushing the CD-ROM driver, the mouse clicked two times. C. Pushing the “setup” file, the mouse clicked two times. Begin to enter installation procedure.
3. Begin to install picture:




4. Choose to install path:




■ RS-232 Software Installation Procedure

5.Choose program group:




6.install progress:



7.install completed:



RS-232 Operation of Software





RS-232 Operation of Software

2.1 Mode () start procedure

After clicking mode () key to start, the program will start the online operation with the equipment and all items in association with mode () will become available for selection.

If the program does not go online with the equipment after starting mode () or in case of interrupted online operations, a message for online failure will appear as follows



picture 2

RS-232 Operation of Software



picture 3

RS-232 Operation of Software

The screenshot shows the RS-232 software interface. On the left, there are three large digital displays showing temperature data: '256.7' (blue background), '261.7' (red background), and '-5.0' (black background). Above these displays are two smaller panels, each showing 'T1-T2' and 'T1-T2' values. To the right of the displays is a table with columns for 'T1', 'T2', and 'T1-T2'. Below the table is a 'Data' button. On the far right, there are three input fields labeled 'Data saving interval', 'Database', and 'Database'. A 'Data' button is also present next to these fields. The interface is titled 'RS-232' and includes a 'File' menu and a 'Data' button. The status bar at the bottom shows 'Data saving interval: 10.000000, 10.000000'.

2.3 T1-T2 and database in display

Click T1-T2 and you have difference of temperatures in 2 sensors.

Click Record to open database and when click Start you will have the data in the sensor in Excel according to saving time interval

Data saving interval in free and independent adjustments as sampling time given in T1 Mode 0

AVG, Average
MAX, Max value
MIN, Min value

T1-T2 value in display

Database


Database route & file name

Data saving interval

Database


picture 4

RS-232 Operation of Software



picture 5

RS-232 Operation of Software



picture 6

RS-232 Operation of Software


4.1 Sensor setting

Click setting of option menu


Specify
T1, T4 sensors for
Hb, Lvs RLL, and load in the
execution program
(for mode 0)

picture 7

RS-232 Operation of Software



■ Battery Replacement

- 1. The symbol “” that appears in the upper left of the LCD display indicates that the battery is running low. Please replace the AAA battery at once to ensure the test accuracy.**
- 2. Remove the battery cover with a screwdriver.**
- 3. Replace the old batteries with four new AAA batteries and lock the battery cover.**
- 4. Prior to replacing the battery, please make certain to remove the thermocouple from the temperature gauge as a safety precaution.**
- 5. When in extended idle, please remove the AAA battery from the temperature gauge and store the temperature gauge in a cool and low-humidity setting.**
- 6. To avoid combustion, DO NOT dispose of batteries into an open flame.**
- 7. Please note the position of the positive and negative polarity when loading battery.**
- 8. Please abide by pertinent laws and regulations when disposing of used batteries.**

■ Caution

1. **Input protection:** The temperature jack carry's a maximum voltage of 34 volts DC or AC.
2. **Temperature jacks:** Designed for insertion of a standard small thermocouple jack which have a center spacing of 7.9 mm between the two prongs.
3. Please **DO NOT** place the HH147 inside a microwave for temperature testing.
4. A correct thermocouple slot should be chosen when operating the temperature gauge.
5. Please **DO NOT** attempt to use a temperature gauge that is not working properly. Consult Omega Customer Service for repair service at once.
6. Please **DO NOT** attempt to operate the temperature gauge around sites where explosive gases, vapor, or dust particles are present.

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2009 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control?

OMEGA...Of Course!

Shop online at omega.comSM

TEMPERATURE

- ☑ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ☑ Wire: Thermocouple, RTD & Thermistor
- ☑ Calibrators & Ice Point References
- ☑ Recorders, Controllers & Process Monitors
- ☑ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ☑ Transducers & Strain Gages
- ☑ Load Cells & Pressure Gages
- ☑ Displacement Transducers
- ☑ Instrumentation & Accessories

FLOW/LEVEL

- ☑ Rotameters, Gas Mass Flowmeters & Flow Computers
- ☑ Air Velocity Indicators
- ☑ Turbine/Paddlewheel Systems
- ☑ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ☑ pH Electrodes, Testers & Accessories
- ☑ Benchtop/Laboratory Meters
- ☑ Controllers, Calibrators, Simulators & Pumps
- ☑ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ☑ Data Acquisition & Engineering Software
- ☑ Communications-Based Acquisition Systems
- ☑ Plug-in Cards for Apple, IBM & Compatibles
- ☑ Data Logging Systems
- ☑ Recorders, Printers & Plotters

HEATERS

- ☑ Heating Cable
- ☑ Cartridge & Strip Heaters
- ☑ Immersion & Band Heaters
- ☑ Flexible Heaters
- ☑ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ☑ Metering & Control Instrumentation
- ☑ Refractometers
- ☑ Pumps & Tubing
- ☑ Air, Soil & Water Monitors
- ☑ Industrial Water & Wastewater Treatment
- ☑ pH, Conductivity & Dissolved Oxygen Instruments